

SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION



- Measurement range: 10 - 100 mm
- Long mechanical life
- Excellent repeatability: <math><0.01\text{ mm}</math>



EASY SENSE


AUTOMATIC READOUT
OF SENSOR SETTINGS

DISPLACEMENT SENSOR
WITH SPRING RETURN



SATEVIS ALPHA-INC
WIRELESS IOT INCLINOMETER SENSOR

SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION



1 WHAT IS EASY-SENSE FUNCTION ?

How often have you experienced false alarms due to incorrect sensor configuration or calibration? **Easy-Sense** helps address this issue by automatically storing and displaying the sensor settings:

- Sensor Type and Measurement Stroke (ex: **Potentiometer**, Measurement stroke: 100mm).
- Sensor Calibration settings and date of calibration .
- Alarms Thresholds Values (Three levels: **Critical**, **Severe**, **Minor**).
- Sensor Zero-offset and date of Sensor zero offset.

• ENHANCED TRACEABILITY

The sensor's calibration settings are securely stored in its internal Flash memory, allowing for easy re-calibration using the Satevis® Link software.

• SIMPLIFIED MAINTENANCE

Users can keep the displacement sensor on-site and easily swap the Satevis® Alpha-Inc in case of sensor redeployment. There's no need to adjust the displacement sensor settings, such as alarm thresholds or zero-offset values.

SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION

• INCREASED FLEXIBILITY

The sensor's zero-offset can be adjusted remotely via the Satevis® cloud application (or a third-party cloud application).


• ADVANCED ALARM MANAGEMENT

Three types of alarm thresholds are available:



- **Low Alarm Threshold:** Triggers an alarm when a data measurement falls below the set threshold.
- **High Alarm Threshold:** Triggers an alarm when a data measurement rises above the set threshold.
- **Mixed Alarm Threshold:** Triggers an alarm when a data measurement changes in two opposite directions.

Additionally, three alarm severity levels are available, allowing users to direct notifications to different emails or activate a dry contact:

- **Minor Level:** The lowest level of alarm.
- **Severe Level:** Medium level of alarm notification.
- **Critical Level:** Highest level of alarm, requiring field intervention.



SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION



• SENSOR ZEROING

Sensor zeroing can be done by holding a magnet on Sensor Zeroing Label or remotely from [Satevis® Cloud](#) application (or [Third-Party Cloud Software](#)).

SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION

TECHNICAL SPECIFICATIONS

PRODUCT REFERENCE

SAT-EASY-SENSE-DISP-SR-MS-YY-CL-XX

MS-YY - Measurement stroke

10mm, 50mm and 100 mm

CL-XX- SENSOR CABLE LENGTH

from 1m to 20 meters

Example: SAT-EASY-SENSE-DISP-SR-50MM-CL-10M

Displacement sensor with spring return, Measurement stroke 50mm, Cable length 10 meters

DISPLACEMENT SENSOR SPECIFICATIONS

Sensor technology	Linear potentiometer with spring return
Measurement stroke	10mm, 50mm and 100mm
Linearity	±0.2% (100 mm) , ±0.5% (50mm, 10mm)
Repeatability	< 0.01mm
Resolution	0.0003mm for 10mm measurement stroke 0.0017mm for 50mm measurement stroke 0.0034mm for 100mm measurement stroke
Resistance	2 kOhm: 10....50mm 5 kOhm : 100mm
Sensor Voltage	3.3VDC Powered directly by Satevis® device
Integrated Analog to Digital Converter	Integrated 15-bit Analog to Digital Converter
Displacement speed	< 5m/s
Mechanical Life	100 millions movements
Casing dimensions	18 mm of diameter
Casing material	Anodized Aluminum
Rod material	stainless steel
Rod diameter	5 mm of diameter
Mechanical mounting	Variable brackets
Waterproofness	IP66
Operating Temperature	-20°C to +80°C
Connection Plug	M8-4Pins connector
Satevis® compatibility	compatible with Satevis® Alph-Inc/Alpha-Inc Kompakt

SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION

EASY-SENSE FUNCTION

Internal Flash Memory

Automatic Readout of Sensor Settings:

- Sensor Type and Range
- Sensor Calibration settings and date of calibration ;
- Alarms Thresholds Values
- Sensor Zero-offset and date of Sensor zero offset

Calibration

Calibration performed at Beanair Lab.




Alarms Management

Three level of Alarms: Critical/Severe/Minor
With High/low and Mixed Alarms Thresholds

Sensor Zeroing

Sensor Zeroing can be performed on site or Remotely from Satevis Cloud Application (or Third-Party Cloud software)

DRAWING



SPRING RETURN DISPLACEMENT SENSOR WITH EASY-SENSE FUNCTION

DISP-SENS (mm)	10	50	100
US (Usefull Stroke)	10	50	100
MS (Mecanical Stroke)	13	53	103

A	
DISP-SENS-SR-MS-10MM	58
DISP-SENS-SR-MS-50MM	104
DISP-SENS-SR-MS-100MM	163

CONTACT US

Headquarter:

BeanAir® Sensors
 Buchholzer Straße 65, 13156
 Berlin, Germany

Email:

info@BeanAir.com

Phone number:

+49 (0)15510558634

